

PART NO. DIA. NO.

DESCRIPTION

DIAL ASSEMBLY

12-1026	Pointer Shaft Bracket
26-457	Dial Scale
95-1149	Dial Pointer
95-1152	Dial Pointer
76-621	Tuning Control Shaft
80-69	Dial Cord Tension Spring (2 used)
83-1885	Dial Cord Support Strip
93-209	.031 x .140 x 7/16 Steel washer-Cad (2 used on 26-457)
114-157	6-32 x 1/2" lg. x 1/4" Hex Hd. S. T. (2 used on 26-457)
114-248	6-20 x 5/16 lg. x 1/4" Hex Hd. S. T. (used on 26-457)
188-128	Retaining Ring (1 ea. used on 76-621 & S-17788)
S-15781	Pointer Pulley Cord & Eyelet Assm. Short
S-15782	Pointer Pulley Cord & Eyelet Assm. Long
S-17798	Pointer Pulley & Shaft Assembly

COILS & CHOKES

95-1148	1st. 1. F. Transformer
95-1149	2nd. 1. F. Transformer
S-11952	R. F. Shunt Coil Assembly
S-14403	R. F. Choke Coil Assembly
S-17709	Oscillator Coil Assembly (B. C.)
S-17710	Detector Coil Assembly (B. C.)

CONDENSERS

22-3	.01 Mfd. Ceramic (3 used)
G16	.004 Mfd. Ceramic
22-1390	470 Mmfd. Mica
22-1674	50 Mmfd. Ceramic
22-1743	Elect. Cond. 40 Mfd.-150V x 40 Mfd. 150V. 20 Mfd.-150V x 200 Mfd. 10V
22-1765	1.2 Mmfd. Molded (2 used)
22-1775	.047 Mfd.
22-1777	.1 Mfd.
22-1778	.047 Mfd. (Molded)
22-1779	.01 Mfd.
22-1780	.0033 Mfd.
22-1784	.01 Mfd.
22-1844	.01 Mfd.
22-1846	.01 Mfd.
22-1886	10 Mmfd. Ceramic
22-1953	Elect. Cond. 12 Mfd. 150V
22-2056	270 Mmfd. Mica (3 used)
22-2071	.022 Mfd.
22-2072	.022 Mfd.
22-2126	250 Mmfd. Ceramic
22-2127	.001 Mfd. Ceramic
22-2279	120 Mmfd. Ceramic
22-2282	Single Section Trimmer
22-2286	Thru Section Variable

RESISTORS

63-1362	Two Section Candelum
63-1743	100 Ohm 1/2W 10% Ins. Res.
63-1744	100 Ohm 1/2W 20% Ins. Res.
63-1750	150 Ohm 1/2W 10% Ins. Res.
63-1761	270 Ohm 1/2W 10% Ins. Res.
63-1783	1000 Ohm 1/2W 10% Ins. Res.
63-1792	1500 Ohm 1/2W 20% Ins. Res.
63-1800	2200 Ohm 1/2W 20% Ins. Res.
63-1807	3300 Ohm 1/2W 20% Ins. Res.
63-1835	15K Ohm 1/2W 20% Ins. Res.
63-1838	18K Ohm 1/2W 10% Ins. Res.
63-1842	22K Ohm 1/2W 20% Ins. Res.
63-1845	27K Ohm 1/2W 10% Ins. Res.
63-1853	68K Ohm 1/2W 20% Ins. Res.

PART NO. DIA. NO.

DESCRIPTION

RESISTORS (Cont'd.)

63-1869	100K Ohm 1/2W 10% Ins. Res.
63-1880	180K Ohm 1/2W 10% Ins. Res.
63-1881	330K Ohm 1/2W 20% Ins. Res.
63-1912	1 Megohm 1/2W (5 used) 20% Ins. Res.
63-1926	2.2 Megohm 1/2W 20% Ins. Res.
63-1940	4.7 " 1/2W (2 used) 20% Ins. Res.
63-1943	5.6 " 1/2W 10% Ins. Res.
63-1954	10 " 1/2W (2 used) 20% Ins. Res.
63-1961	15 " 1/2W 20% Ins. Res.
63-2018	130 Ohm 3W Zipohm 19%
63-2276	Volume Control & Switch
63-2817	Two Section Zipohm

MISCELLANEOUS

11-104	Line Cord & Plug
13-37	Cap & Insulator (used on S-15785)
44-29	Phone Socket
49-868	5 1/4" PM Speaker
78-274	2 C5091 Cone
78-543	Elect. Cond. Socket
78-802	Four Contact Socket
78-806	Wavemagnet Socket
78-817	Miniature Tube Socket
78-844	Miniature Tube Socket
78-845	Miniature Tube Socket (3 used)
85-500	Power Changeover Switch
85-503	Band Switch
94-295	Gang Cond. & Spkr. Mtg. Bushing (6 used) 6-32 x 1 1/8" lg. x 1/4" Fl. M.S. Steel (used on 212-10)
114-308	Strain Relief Crommet - Male
125-81	Strain Relief Crommet - Female
139-86	Speaker Baffle
149-86	Iron Core (16 used)
196-174	Speaker Gasket
212-5	Selenium Rectifier
212-575	Battery Cams & Socket Assembly
S-15715	Voltage Adapter Assembly

CABINET PARTS

12-1082	Telescoping Ant. Mtg. Brkt.
14-1303	Cabinet for H500 Portable Model
18-676	Packing Carton - Complete
17-67	Telescoping Ant. Ret. Clamp
18-134	Wavemagnet Cable Ret. Clip
18-188	Cable Retaining Clip
38-46	Cabinet Handle
48-73	Cabinet Back Cover Hinge (2 used)
48-912	Band Switch Knob (7 used)
48-913	Tuning & Vol. Control Knobs (2 used)
54-295	Wavemagnet Ret. Nut (#10-32) (used on S-17747)
54-296	Wavemagnet Ret. Nut (#10-32) (used on S-17747)
57-1784	Front Panel Evencheen
57-1725	Emblem Plate
58-179	Three Prong Plug (1 ea. used on S-15799 & S-15905)
70-122	#6 x 5/16 H.H.W. S. Steel (2 used on 19-188)
70-168	#4 x 1/2" Phill. R.H. Wood Screw
70-169	Brass-Bk. Ox. (3 used on S-1724)
70-169	#4 x 3/4" Phill. R.H. Wood Screw
70-169	Brass-Bk. Ox. (4 used on S-1724)
87-1876	Four Button Feet Strip
91-367	Handle Mtg. Stud (2 used)
114-197	Hexagon Washer Hd. S. T. Screw (2 used on Chassis Mtg.)
156-42	Door Latch (Upper half)
156-43	Door Latch (Lower half)
157-7	Strike Fastener (2 used)
157-8	Strike Fastener (2 used)
159-48	Snap Button (2 used on S-15805 & 2 used on S-17782)

PART NO. DIA. NO.

DESCRIPTION

CABINET PARTS (Cont'd.)

159-49	Snap Button (4 used on S17747 & 2 used on 19-134 & S-17782)
199-119	Antenna Insulating Sleeve
202-869	Instruction Book & Station Log
202-870	Service Notes
202-872	Weather Bureau Bulletin
202-880	Short Wave Station List
S-15635	Wavemagnet Section Cup Assm. (2 used)
S-15722	Antenna Knob & Latch Spring Assembly
S-15799	Wavemagnet Cable Assembly
S-15802	Telescoping Antenna Assembly
S-15805	Wavemagnet Ext. Cable Assembly
S-17743	Eyelet & Wire Assembly
S-17744	Front Cover Hinge & Terminal Assm. (R.H.)
S-18431	Wavemagnet Assembly
S-17782	Tube Holder Assembly

FREQUENCY BAND SWITCH ASSEMBLY

12-1025	Band Switch Mtg. Brkt.
22-3	.01 Mfd. Ceramic
C5	470 Mmfd. Mica
C3	25 Mmfd. Ceramic
C30	2750 Mmfd. Mica
C39	50 Mmfd. Ceramic
C35	10 Mmfd. Ceramic
C8	.001 Mfd.
C13	120 Mmfd. Ceramic
C34	120 Mmfd. Ceramic
C39	3000 Mmfd. Mica
C29	22-2283
C33A, 33B	Two Section Trimmers
C36A, 36B	Two Section Trimmers
C37A, 37B	Two Section Trimmers
R31	4.7 Ohm W.W. 1/2W 10% Ins. Res.
R29	10 Ohm 1/2W 10% Ins. Res.
R30	220 Ohm 1/2W 10% Ins. Res.
S1	Band Switch
S5	Voltage Change Switch
159-96	Iron Core (1 used on S-17730 & S-17731)
S-18429	Antenna Loading Coil Assembly
S-16888	Band Switch, Brkt. & Coil Assembly
L19	R.F. Coil Assembly (16M)
L17	R.F. Coil Assembly (19M)
L16	R.F. Coil Assembly (25M)
L15	R.F. Coil Assembly (31M)
L12	Asst. Coil Assembly (16M)
L11	Asst. Coil Assembly (19M)
L10	Asst. Coil Assembly (25M)
L9	Asst. Coil Assembly (31M)
L19	R.F. Coil Assembly (2-4 MC)
L40	R.F. Coil Assembly (4-8 MC)
L13	Asst. Coil Assembly (2-4 MC)
L14	Asst. Coil Assembly (4-8 MC)
L24	Osc. Coil Assembly (16M)
L23	Osc. Coil Assembly (25M)
L22	Osc. Coil Assembly (31M)
L21	Osc. Coil Assembly (4-8 MC)
L21	Osc. Coil Assembly (4-8 MC)
L25, 26	Osc. Coil Assembly (2-4 MC)

VOLTAGE ADAPTER

57-1564	Voltage Indicator Plate
58-182	Two Prong Plug
63-2155	Dual Resistor 620 Ohm 15W & 1200 Ohm - 7W
85-473	Three Position Switch
112-704	Thumb Screw
212-9	Selenium Rectifier
S-15715	Voltage Adapter Assm. (Complete)